

INSTRUCTIONS FOR USE

1. Assess the liquid that was spilt before applying any absorbent. Consult the spilt products SDS to assist in ensuring that all appropriate safety precautions are taken including the use of appropriate PPE equipment..
2. Contain the spill using the absorbent or containment sock.
3. Apply absorbent to cover spill.
4. The mix of absorbent and the spill should appear dry, if not, apply more absorbent until it looks dry.
5. Using a stiff broom, sweep absorbent over the spill area.
6. If the mix does not appear dry or there remains an oily film on the surface, apply additional absorbent.
7. Use pads to wipe clean any area or equipment not cleaned by the absorbent.
8. Dispose of in accordance with local government regulations.
9. Complete an incident report and file.
10. Re-stock kit with replacement stock.

CONTENTS	ES-PWB-120-Y	120L Yellow Wheelie Bin	1
	ES-PPGP-400	Poly Pads GP - 48x43cm Heavy Weight - Dimpled & Perforated	25
	ES-A-FS-10	FloorSweep 10kg bag	2
	ES-SOGP-75-1.2	Grey Absorbent Socks - GP - 1.2m x 75mm	3
	ES-P-GP	SpillSmart GP Pillow (grey cover) 45cm x 45cm	1
	ES-G-NL	Pair of Nitrile Gloves	2
	ES-WB	SpillSmart Contaminated Waste Bags - 450mm x 720mm	7
	ES-DPB	Dust Pan & Brush	1
	ES-ST-GP	Spill Kit Sticker	1
	ES-SKIN	Spill Kit Instructions	1

Available from

